



## \*\* Assembly Instructions \*\*

### Designer Butterfly Favor Box with Milkweed Seeds

- Remove contents from packaging and clear a work space for assembly.
- Take each pouch and scoop 1 level spoon full of milkweed seeds using the plastic spoon provided. Pour seeds into pouch. Repeat this step until all pouches are filled.
- Optional – attach instruction tag to pouch:
  - Punch a small hole (use a 1/8” or 1/4” hole punch) on the left edge of the instruction tag.
  - String pouch laces through the hole in the instruction tag, synch, and then tie.
- Synch pouch laces and tie.
- Lay unassembled box on a flat surface or table with the printing side facing down and the butterfly wings on the end of the bands opposite of where you are positioned. (The butterfly wings on the bands look like two “arms” lifted up in the air.)
- Crease and fold the box along the 6 main score marks.
- Place pouch with seeds and instruction tag on rectangular base of the box.
- Fold the two bottom corners closest to you and bring the corners together so they are touching.
- Keeping the two corners together, bend upward so that a “pyramid” shape is formed and covering the pouch.
- Close the remaining flap and bend “arms” around the box so that the two butterfly wings are coming together and facing you.
- Slide the arm on the right up and over the arm on the left so that the butterfly wings lock into the triangular shaped slot.
- Adjust and straighten box.

---

If you have any questions about this assembly, please contact us:  
Swallowtail Farms, Inc. ☎ [www.swallowtailfarms.com](http://www.swallowtailfarms.com) ☎ 1-888-441-4902